


Quick Start Guide

1. Unpacking Package Contents

Unpack your document camera package and check for major components.


- 1) Document camera
- 2) Black Pad
- 3) USB cable
- 4) Software DVD
- 5) Quick Start Guide



2. Connecting the Document Camera

- 1) Connect one end of the USB cable to the back of the document camera,
- 2) Connect the other end of the USB cable to an available USB port on your computer.

NOTE: The USB-A port of the USB cable has two ports; please connect the master port to the computer as indicated by the graphic on the right.




3. Installing the Software

- 1) Place the Software DVD into a DVD drive. Then, click "Microtek CamShop" and follow the on-screen instructions to install the software.
- 2) Click on other software to install if desired. Then, click "Exit" when all the software has been installed.

NOTE:

- If the Software Installer screen does not come up automatically, double-click the following in succession: "My Computer"; the DVD-ROM icon; then "cdsetup.exe" to start the installer program.
- If your computer doesn't have a DVD drive, please download the software from Microtek website "www.microtek.com" and install it on your computer.



4. Getting Started

- 1) Place the Black Pad on a flat and stable surface. Then, place the document camera on the Black Pad and align it with the position markers, as shown on the right picture.
- 2) Place the document to be captured facing up on the Black Pad.
- 3) Double-click the "CamShop" icon on the Windows desktop to activate the software. If the document camera is detected, you should be able to see the real-time preview video feed from the camera.
- 4) Click the "Language" (🌐) button on the upper-right corner of the main window, and select the on-screen display language if desired.
- 5) Select the desired function mode and specify shooting-related parameter settings for your own. Then, click the "Scan" (or Start) button to capture images.



NOTE: For more detailed operations of the CamShop software, please refer to the User Manual on the included Software DVD.

Frequently Asked Questions (FAQ)

Unable to detect the device.	<ul style="list-style-type: none"> • Check whether the USB cable is connected properly. • Switch and connect to another available USB port on your computer.
Image is unclear.	<ul style="list-style-type: none"> • Insufficient light; please capture in an environment with sufficient lighting. • Try to turn on the fill light for capturing. • Confirm whether the resolution is the highest resolution.
In Device Manager, the imaging equipment has a yellow exclamation mark.	<ul style="list-style-type: none"> • Download the USBVideo.sys file that corresponds to your system and copy it into the C:\Windows\System32 folder. • The customer's computer is missing the camera driver; install the camera driver.
The image is very small after shooting.	<ul style="list-style-type: none"> • Change the resolution in the software. • If there is only one resolution, please change the USB port or change to another computer with a USB port.